



Push Button Non-Illuminated Switches – 22Ømm

ENCLOSURES  
CONTROL STATIONS  
SWITCHES  
ACCESSORIES


**DPB22-D – Double Push Button**




**DPB22-E & DPB22-P – Elevation Head**




**DPB22-F & DPB22-L – Flush Head**




**DPB22-K – Mushroom Head with Key**




**DPB22-M – Momentary Mushroom Head**



**DPB22-R – Twist to Reset Mushroom Head**



**DPB22-S – Push-pull Stop Mushroom Head**



**DPB22 Non-illuminated – 22Ømm**

Non-illuminated push button switches come with 12 different types of heads: 35Ø, 40Ø and 65Ø; eight types of contact blocks; a choice of cap colours and voltage ratings.

- Materials: Please see page 12
- Types:
  - Double Push Button (**D**)
  - Elevation Head (**E**) and Latching Elevation Head push-push to release (**P**)
  - Flush Head (**F**) and Latching Flush Head push-push to release (**L**)
  - Mushroom Head push-push to release (**G**)
  - Emergency Stop Mushroom Head 40Ø with key (**K**)

- Emergency Stop Mushroom Head 40Ø (**M**)
- Reset Mushroom Head 40Ø (**R**)
- Emergency Stop Reset push-pull Stop Mushroom Head 35Ø (**S**)
- Reset Mushroom Head 65Ø (**V**)

Available End 2010 –

- Mushroom Head 65Ø (**B**)
- 8x Contact blocks configurations
- Cap colours:
  - Red (**R**)
  - Green (**G**)
  - Yellow (**Y**)
  - Blue (**S**)
  - Black (**B**)
  - White (**W**)
- Voltage rating: Please see page 12